



# Ultraply XL™ Premium Underlayment®

## Installation Instructions:

### Acclimation:

Condition Ultraply XL™ Underlayment panels 18 to 48 hours to the room environment in which they will be installed.

- Install Ultraply XL™ with the stamp side down before installing the finished floor.
- Install the long dimension of the panel perpendicular to the floor joists for maximum rigidity.
- Make sure your Ultraply XL™ Underlayment seams offset any sub-floor panel seam by at least 6”.
- Stagger panels, ashlar fashion, so that four corners do not meet. Offset Underlayment joints by at least 16”.
- Leave a minimum 1/8” gap at walls.
- Lightly butt all panels, but do not force sheets into place.
- Fasten panels securely to a structurally sound, smooth, clean and dry wood sub-floor with divergent staples with chiseled ends &/or non-staining, galvanized ring groove shank nails.
- Make sure fasteners do not penetrate through the sub-floor or into the floor joists.
- Position fasteners in the field on 4” inch centers.
- Attach edge fasteners 1 ½” apart and 3/8” from edge.
- Set fasteners flush or slightly below the panel surface.
- Fill all edge joints and other surface depressions with a **PORTLAND BASED LATEX MODIFIED PATCH**, and sand smooth. Make sure patch is **FULLY DRY** before installing the finished floor.

### \* Notes & Exceptions:

The Moreland Company has the highest quality of standards in the market. Environment and temperature should be noted to ensure acclimation. The finished floor should be installed immediately after Ultraply XL™ Premium Underlayment to prevent job site influenced damage. Moreland Company is not responsible for faulty installation. No defective material is to be installed. Final inspection of each panel is the responsibility of the installer.

Please visit our website at [www.morelandcompany.com](http://www.morelandcompany.com) or [www.ultraply.net](http://www.ultraply.net)